

# ROMANOFF INTERNATIONAL

SUPPLY CORPORATION

9 DEFOREST STREET

AMITYVILLE, NEW YORK, U.S.A. 11701

631 842-2400 FAX 631 842-0028

Email: [sales@romanoff.com](mailto:sales@romanoff.com) [www.romanoff.com](http://www.romanoff.com)

## INSTRUCTIONS FOR #8100 DIGIMELT FURNACE

- Verify your voltage, 110V or 220V and connect to power source.
- Close the cover of the melter, with the graphite crucible inside the melting chamber.
- Press the red power switch to the "ON" position.
- Push the "P" button and then press the "UP" & "DOWN" arrows to set the desired temperature recommended for your metal. When the button is released, the controller will show the actual temperature inside the melter.
- When the metal has melted, use the special tongs provided to lift out the crucible or you may lift the entire melter by the black coated handle, pouring carefully.

December, 2006