



ROMANOFF

INTERNATIONAL SUPPLY CORPORATION

9 DeForest Street • Amityville • New York, USA 11701

631-842-2400 • Fax 631-842-0028

email: romanoff1@aol.com • www.romanoff.com



INVESTMENT WATER BLAST CABINET

Z50-002-R (110 V)

Z50-002A-R (220 V)

1. Connect to your power source.
2. Connect water inlet valve on lower right side of cabinet to cold water source (1/2" NPT) and then open the valve.
3. Connect right or left side drain to a barrel or tank into which the water from the cabinet will flow. It is best to connect to a barrel or tank first to prevent any investment from going into your drainpipe.
4. Screw plug into drain side not being used.
5. Turn on switch above viewing glass.
6. Place foot pedal in convenient spot on the floor in the front of the cabinet away from any water.
7. Place casted flasks inside the cabinet from the right or left side.
8. Put your hands into the gloves.
9. Firmly hold the tree to be cleaned and step on the foot pedal until investment is removed.
10. On some models there is an additional valve on the right side of the cabinet above the water inlet valve. This is only for the purpose of attaching an additional external water pressure gun. When not being used, the valve should be closed.
11. The oil in the high pressure pump should be changed at least every three months. Use a high quality SAE 30 grade non-detergent oil. The pump is accessed from the back of the cabinet.

***IMPORTANT:** NEVER STEP ON THE FOOT PEDAL WITHOUT THE SIDE DOORS CLOSED AND ALWAYS WEAR THE GLOVES.

5/2000



Serving the White Metal and Precious Metal Industries since 1949...and Still Growing!
Manufacturers of Spin Casting and Lost Wax Investment Equipment.
Suppliers of all materials used to manufacture jewelry.

